

# TheMagicTouch USA

---

## Graphtec 5000 series setup

1. Insert Graphtec CD supplied with plotter
  - a. "Install Craft ROBO Pro Software"
  - b. Connect the plotter and follow the Found New Hardware Wizard to install plotter drivers
  
2. Install the MagiCut software
  - a. Click the "Install Cutter Drivers Now!" button at the end of the installation process
  - b. Choose the CE5000-40CRP GPGL
  
3. Make the following changes on the plotter
  - a. Load media and press Enter to read the media size
  - b. Press PAUSE then NEXT until you see LENGTH UNIT
    - i. ENTER – MM (change setting by using up arrow)
    - ii. ENTER again to save changes
  - c. Press NEXT until you see COMMAND
    - i. ENTER – GPGL – ENTER
    - ii. Set STEP SIZE to .025 – ENTER
  - d. NEXT until you see AUTO REG MARK
    - i. ENTER – (MARK MODE) ENTER – OFF – ENTER
    - ii. NEXT until you see MARK TYPE
    - iii. ENTER – 2 – ENTER
    - iv. NEXT – (MARK SIZE) ENTER – 10 – ENTER
  - e. PAUSE to return to main menu