

# Wow 7.1 Professional



## Guide and Instructions



100 F  
WASH  
WARM



DO NOT  
TUMBLE DRY



DO NOT  
IRON OVER  
DECORATION



NO CHLORINE  
BLEACH

Call Support Before Using:  
888-349-2378

1. Set Heat Press to 125C/255F and maximum pressure. Use temperature test strips to verify your heat press's actual surface temperature.
2. Print mask as black and white negative mirrored on high quality laser plain paper to avoid shrinkage of the mask and mismatch of mSheet to iSheet. See "Mask How To Guide" on our website for help.
3. Place WoW Pad on Heat Press with smooth side up and pre-press for 10 seconds when you start cold.

*Note: Proper temperature at the first step is important for a good final result*



4. Place mSheet coated side up on WoW Pad and plain paper Mask on top. Cover with Release Paper and press for 10 seconds. Open press and strip Mask Paper off the mSheet immediately and in one quick go without stopping.

*Note: Do not remove Release Paper before you strip the Mask, it will keep the stack flat on the WoW Pad as desired.*



5. Remove WoW Pad off the Heat Press. Place Release Paper on Heat Press and iSheet printed side up on top. Place and align mSheet on top to match the Image(s) with the masked white Film areas. Cover with WoW Pad smooth side up and press for 30 seconds.



Open Heat Press, take the mSheet and iSheet stack of the Press. Wait until the stack is cold and strip mSheet backing paper including the outer border of the white film off the iSheet.



6. Place Garment on the Heat Press and position iSheet with final transfer face down on top. Press for 3-5 seconds, for finer details and/or coarser weave up to 10 seconds. Open Heat Press and let transfer turn cold. Lift and grab one corner of the iSheet backing paper and strip off very quick in one quick sssssshhtt (flash). Note: If you encounter any grey color Coating Residue or white spots outside the Image area you can stick regular office cello tape on it to remove it. Finally, cover with Silicone Sheet and press again for 15 seconds. Let cool down for a few seconds and remove Release Paper or SiliconeSheet. In case of stains on both sheets press them for 15 seconds on Plain Paper to clean.

